

## Remote Control Settings

**ON/OFF**  
Press the "On/off" button, the light keeps permanently on or off. Press "Auto Mode", "Reset" or "Apply" buttons to quit from this mode.

**Auto Mode**  
Press "Auto Mode" button, the sensor starts to work and all settings remain the same before the light gets switched on/off.

**Reset**  
1. Press "Reset" button, change brightness to max level.  
2. Press "Reset" button, products with DIP switch will be controlled by DIP switches; otherwise all the setting will be just initial, that is 100% detection range, hold time 5S, no stand-by time and daylight threshold disabled.

Flick after press any button

Flick only after press "Apply" button

**+/-**  
1. To adjust brightness 10-100% in on/off mode.  
2. To adjust highest brightness 60-100% in sensor mode.

**Start**  
Press "Start" to customize scene, users can change detection range, daylight threshold, holdtime, standby dimming level and standby period.

**Memory**  
1. Press "Memory" to save all the settings.  
2. The settings remained as the last time if not get resetted values.

**Apply**  
1. Press "Apply" to deliver the saved setting.  
2. Press "Apply" without "memory" will make all the setting one-time operation.  
3. Settings should be done within 30S, otherwise it exits memory mode.

Detection area (Press to define detection area 100%/75%/50%/25%.)

Hold time (Press to define holdtime 5s/30s/1min/3min /5min/10min/20min/30min .)

Stand-by dimming level (Press to define stand-by dimming level 10%/20%/30%/50%.)

Stand-by period (Press to define stand-by period 0s/10s/30s/1min/5min/10min/30min/+∞)  
Note: "0s" means no standby period; "+∞" means unlimited standby period.

Daylight threshold (Press to define daylight level 2Lux/10Lux/30Lux/50Lux/80Lux/120Lux/Disable.)  
Note: Disable means light will be turned on once sensor detects movement, regardless of the ambient lux.

**Test (2s)**  
The button "Test (2s)" is for testing purpose after commissioning. Pressing this button, the sensor goes to test mode ( hold time is only 2s )

### Technical Data

Order Code	Part No.	Model No.	Note
213979	213979	HD03R	Remote controller for more setting options

### Notes:

- Settings will be saved automatically and remain until you press reset again.
- Light will flicker when setting each parameter.

